


SureFlap Microchip Pet Door Installation Dimensions

External Frame



Not to scale

Please use the inside edge of the external frame of your pet door as a cut out template.
Full installation instructions can be found in the product manual